

(REVISED 10-2009)
LS 4 INSTALLATION INSTRUCTIONS
FOR ANY MODEL LS 4 PURCHASED AFTER OCT. 2009

1. Determine the area where the shelter will be installed and excavate a 9'Lx11'W hole 69" deep.
2. After hole is dug be sure the walls are as square as possible.
3. Level the bottom of the hole.
4. Place 2 ½" steel pipes through the pvc tubes on the bottom of shelter as shown in illustration. 1a.
5. Lower shelter into hole and check for level both directions.
6. Place some dirt around pipes on each side and smooth off so that the dirt is level with the top of the pipes. This will give the anchor boards a flat surface to lie on.
7. Place anchor boards over steel pipe rib side up as shown in illustration 2a and 2b.
8. You may now begin to backfill the hole.
9. Bring surface to rough grade and level off best as possible As shown in illustration 3a. (DIRT SHOULD BE MOUNDED TO COVER SHELTER TOP BEHIND DOOR 9-12")
10. Your installation is now complete.



Illustration 1a.

Storm tek 3 shown for ill. Purpose only



Illustration 2a.
illustration purposes only.)

(shown out of hole for



Illustration 2b



Illustration 3a